

This handy tool guts, strips and crimps RG-58, RG-59 and RG-6 cables and connectors. It strips the center core or outer jacket by rotating the tool between 2 to 3 times around the cable. Crimp connectors are installed easily by squeezing the handles.